

BrickHouse TrackView LBS Manager App Guide

The LBS Manager app is for tracking BrickHouse Security GPS units. It is free and available for Android phones, tablets, iOS smartphones, and iPads.


It features the following capabilities: tracking unit location and moving state, including trips, stops, and parks, monitoring data actuality or the time passed from the last message received, and the latest events like trip and parking.

Log In

Please open the app and enter the Platform URL: gps.brickhousesecurity.com. Log in using the username and password provided in the email we sent you.

It's important to note that the username and password are case-sensitive, so please make sure to enter them exactly as they appear in the email.

If you forgot your password, you can reset it by tapping the "Forgot password" link and following the prompts.




Dashboard


Once logged in, you will see the list of units active on the account under the Dashboard tab.

Adding units to the list

- Displayed at the top is your Account ID #.
- 2. Tap the icon to the right of your account ID and select the unit card you want to view.
- 3. You can use the search or the Filter button to select all the items filtered by the search.
- 4. Tapping the refresh icon will reload the page.
- 5. 5. Tap the icon to display the menu.







Viewing your Device Info


The Dashboard gives access to the main tracking features. From the dashboard, tap the device details to view the map.


The details will include the Summary and History tabs.

Tap the icon to access a ground-level, 360-degree panoramic view of a location,

and tap the icon to select the Map style from Satellite, Terrain, or Default view.

Scroll upwards to view the tracker information.





Summary Tab

The Summary tab will display the day's trip duration, including the Start and Last Location and their coordinates.

Aside from the device info, it will also display the speed, the start and stop time of the trip, and when the unit was last stationary or moving.

History Tab

The History tab shows the past tracking location of the unit. By default, the data is displayed for the current day.

۲ Summary History North Ma North Perry Perry Fairport Harbor Painesville Montville < > 05/08/2024 Map all 05/08/2024 743 Thompson Rd, THOMPSON, OH, 44086, US 04:29:02 PM > 0 MPH 05/08/2024 743 Thompson Rd, THOMPSON, OH, 44086, US 04:28:49 PM > 0 MPH

Selecting a date will display the historic tracking data for that day.

Use the < and > arrows to change the date or tap the date to open the calendar.

Tap the Map all to show the history for the selected date.

Once the results populate, you can either tap on the arrow on the map or tap the device summary to show you the data including the date and time, address, speed, and coordinates.

Tracking

The map can be viewed by tapping the Tracking tab at the menu at the bottom right of the page. All units selected on the dashboard tab will be displayed on the map. The default view will center on your trackers and zoom out to a level that shows all your units.

Tap the icons in the lower-left corner to change the map settings like street view and map layers.

Interacting with Map

To quickly find a specific unit, type its name in the search bar or use the Filter button.

Zooming

Use the following screen gestures:


- Double tap zoom in.
- Two fingers stretch/pinch zoom in and zoom out, correspondingly.

Tilt Gestures

You can tilt the map by placing two fingers on it and moving them up (increasing tilt angle) or down (decreasing tilt angle).

Map Rotation

To rotate the map, place two fingers and apply a rotation motion. After the map has been rotated, a compass icon appears in the top right corner. Tap it to return the map to the default position.



Groups

The list shows all units that are active on your account.

Tapping on a specific unit card will show you the device details, Time Settings, and Hours of Operation.

66611		0
Peggy		0
ASSET	INDIVIDUAL	VEHICLE
ASSET	INDIVIDOAL	VENICLE
4	0	0

GROUP NAM 66611	E	TIME ZONE (-5) US Eastern	
SUPERVISOR NAME		UNITS OF MEASURE Imperial	
DESCRIPTION Peggy		VOLUME MEASUREMENT UNIT Gallon	
		temperature measure unit Fahrenheit	
Group Details Time	Settings Hours Of Operation	AREA MEASUREMENT UNIT Square Feet	
VEEK DAYS	SET DEFAULT	COUNTRY United States	
SUN MON TUE	WED THU FRI SAT	Use DayLight Saving Time (14/03/2021 02:00 AM - 07/11/2021 02:00 AM)	
IMEFRAME	SET DEFAULT		
STARTING HOURS	ENDING HOURS		

Save positional records during hours of operation Only

Settings

You can customize the app settings based on your preference. To exit the application, tap the Log Out icon.

